User's Manual

Ematic SoundBase
ESB214

Connect the SoundBase ESB214 to your TV system

Step1 : Place the system

A. Move your TV aside and turn it so you can see the connection panel.
B. Place the SoundBase ESB214 where you had your TV.



Placement guidance:

The SoundBase ESB214 is designed to fit under TVs that weigh no more than 40 lb (18 kg) and have bases no wider than 20" (508 mm) and no deeper than 10¼" (260 mm). Many 42" and most 32" TVs and smaller meet these requirements.

Step 2: Connect the SoundBase system to the Power



Connect the Power adaptor to the SoundBase and the power source, Then turn on the Power,The LED display will be light up.

The LED display will be light up

Step 3: connect the SoundBase to the TV system



Step 4: Check your TV settings

To enjoy the full benefit of hearing TV audio through the SoundBse speaker system, the internal speakers in your TV should be turned off. Also, you need to make sure that some audio settings do not inhibit the audio output signal.

Note: Check the user manual for your TV for help on using the TV menus and changing any TV settings. Manufacturers usually make user manuals available on their web sites.

A. Turn on your TV.

B. Go to the TV menu and select Audio, Sound, or Speaker Settings.

C. Look for the menu item that allows you to turn off the TV speakers. This menu item may be called Speakers On/Offor something closely related.If there is no setting for turning the TV speakers off, adjust the TV volume to its lowest setting.

D. If you decided to use either an optical or coaxial digital audio output, look for a menu item in the Audio Settings that may affect digital audio output. You may have to select the digital output you want to use.

Step 5 Choose the correct Correct signal input



Press Power Button either on the SounBase or the remote to open it.
Then press MODE button to choose the correct Audio source form TV, DVD play, ect.
Connect the SoundBase to other device



Other Function instruction

EQ Function

Press the EQ button to choose from the equalizer options: music, movie, standard, etc.

Bluetooth™ Mode

Press the MODE button to switch to Bluetooth mode.

1. You will hear a tone, and a green light will flash.
2. Scan for devices in your Bluetooth settings.
3. Connect to ESB214 when scan has completed.
4. The default password is: 0000.



Specifications

Soundbar tabletop speaker with built-in Subwoofer
High efficiency Drivers and amplifier create excellent Sound quality
Bring your movies and music to life with a built-in subwoofer and dynamic 3D Sound
Ideal design for flat panel televisions
Use on any flat surface - no wall mounting necessary
Works with iPod, iPhone, iPad, TV & MP3 players
Input:AC In;Power Switch;Digital Coaxial Input;Analog Input 1;Analog Input 2
High density wood MDF cabinet-Not plastic
Digital LED display
Controll remote

Power: AC100~245V
RMS: 50W
Frequency Response: 50Hz ~ 18KHz

Size:W500*H78*D320mm

Customer Support

Visit ematic.us/support for customer service regarding your device. To submit a request, fill out the required information online. You will be provided a ticket number regarding your issue, which you can refer to when contacting us further.

©2014 Ematic. All Rights Reserved. Bluetooth and the Bluetooth logo are trademark of Bluetooth SIG, Inc and used by Ematic under a license. 1 Year warranty from the date of purchase, 90 dys only on labor.